ERTL PEDAL TRACTOR **ASSEMBLY INSTRUCTIONS**



TOMY:

Your pedal tractor's durable construction offers your child years of enjoyment when properly assembled and maintained. Please read all instructions carefully prior to beginning assembly and keep this instruction manual on file for future reference.

WARNING:


ADULT ASSEMBLY IS REQUIRED

To reduce the risk of injury, keep small parts out of reach of children. This product requires assembly by an adult prior to use. This product should at all times, be used by the child under direct supervision of an adult and should not be used on or near roads, steps, stairways, hills or pool areas. Children should wear shoes.


DO NOT ALLOW MORE THAN ONE CHILD TO RIDE AT A TIME.

TOOLS REQUIRED:


- · Wrench in the package, M6, M5
- · Medium Phillips and straight screwdrivers
- · Pliers or vise grips
- · Crescent wrench or open end metric wrenches
- Hammer
- Oil
- Block of wood
- · Capnut driver in the package



FAMILIARIZE YOURSELF WITH THIS HARDWARE:



(33) Cotter Key 2 Each



(26) M6 x 15 Bolt 6 Each

4 Each

- (30) Ø19 OD x Ø 11.8 ID Washer 4 Each
- (34) Tooth Washer Nut M6 6 Fach


- (27) M5 x 38 Screw 1 Each

б Each

(35) Tooth Washer Nut M5

(32) Ø14 OD x Ø4 ID Washer

2 Each






(28) M4 x 6 Screw 7 Each



(37) Capnut 11mm

8 Each






- - (31) ø24 OD x ø13 ID Washer 4 Each


STEP 1

In order to protect your flooring or carpet from damage or stains it is suggested that you assemble your tractor-cycle in the lid of the shipping carton. To begin assembly, lay the tractor body on its side over one wall of carton lid, as shown. Place steering wheel onto steering shaft. Align hole in steering shaft with those in steering wheel and insert M5 x 31 screw through holes. Thread tooth washer nut M5 onto screw and tighten. Place seat into the desired position on seat base of tractor body, (this can be further adjusted to suit child after final assembly). Align holes in seat with desired hole in body and tap the M5 x 75 screw through the holes with a hammer. Thread tooth washer nut M5 on and tighten.




STEP 2

Assemble pedals to pedal crank arm. Slip ø19 OD x 11.8 ID washer onto one end of pedal crank. Slip pedal onto crank with circular recess at top. Place capnut into position and proceed to Subassembly B.




Place pedal crank over edge of workbench or table, as shown. Using the capnut driver supplied, hammer capnut onto end of pedal crank. Repeat Subassemblies A and B.




STEP 3

Turn tractor over in carton lid so that it rests on seat and steering wheel. Remove chain from its protective carton, (careful, it's a bit greasy), drape chain over assembled pedal crank arm as shown, and feed chain through "chain tunnel" of body toward rear of tractor, finally resting pedal crank arm in pedal slot. Reaching into rear chain access hole of body, lift end of chain out of body. Pass rear axle through loop of chain; squared end of rear axle shaft must be on left side of tractor when upside down, (see illustration). Place rear axle in rear axle slot of body. Use special included wrench to hold kepnuts for assembly of pedal arm and rear hubs. Pass M5 x 12 screws through body and pedal bearing backing plate, trapping pedal bearing into cupped recess in body; thread tooth washer nut M5 onto bolts and tighten. Slide assembled axle housing (from Subassembly Step 2) over one end of axle. One at a time, pass M6 x 15 bolts through holes in housing and body, (this is easier with housing in full forward position). Thread nuts onto bolts - DO NOT TIGHTEN. Repeat this assembly for other side. To adjust chain tension, grab rear axle with fingers on both sides of gear, pull chain back so that chain is snug. While holding gear in this position, tighten one bolt on each side to hold axle in place, then tighten remainder of bolts. Rotate pedal to check operation and oil chain liberally while rotating.




STEP 4



STEP 5

Assemble front wheels to front axle. Place a front wheel onto axle hub spindle; position a capnut onto end of axle hub spindle.




Carefully place front axle on edge of workbench (or a properly protected table) and pound capnut onto spindle as shown. It is critical to support axle hubs as shown for proper front wheel alignment.

Repeat for opposite side.


STEP 6

Position tractor close to one edge of carton lid. Find the rear wheel which has a slot for the axle on one side, and slide it onto the right axle as shown with the slot to the outside. Slide ø24 OD x ø13 ID washer onto axle. Insert cotter key throughhole in one side of axle and use a pair of pliers to bend the prongs around axle. Pound hubcap into position using a block of wood and a hammer. Repeat for other side; make sure you keep the hubcap side of the wheel to the outside. Secure rear axle guard into opening in rear body with M4 x 6 screws. Repeat for pedal guard. Place assembled front axle in body as illustrated. With the tractor in a nose-down position, slide the front axle pin into place and secure with the M5 x 38 screw and square nut M5. Inset steering pin through tie rod as shown making sure pins are facing up. Drive a capnut onto stering pin. Flip the pedal tractor over and apply decals per directions on the sheet. You ERTL pedal tractor is finished and ready for years of unending play!



3

PARTS LIST



| Ref. No. | Description | John Deere Part No. |
|----------|-----------------------------------|---------------------|
| 1 1A | Body Grille | Not Available |
| 2 3 | Right Axle Hub Left Axle Hub | P10340 |
| 4 5 | Pedal Guard Axle Guard | P10333 |
| 6 | Tie Rod | P10055 |
| 7 | Front Axle | P10052 |
| 8A | Left Front Wheel | P10174 |
| 8B | Right Front Wheel | P10175 |
| 9 | Rear Axle Hub | P10050 |
| 10 | 2.75" Rear Idle Wheel - Wide | P10083 |
| 11 | 2.75" Rear Drive Wheel - Wide | P10084 |
| 12 | Seat - Grey Decal Sheet | P10651 P10645 |

| | _ 00000 000000 | 1 100-10 | | | |
|--|----------------------------|--|--------------------|---------------------------|----------|
| COMMON Ref. No. | N PARTS Description | Part No. | HARDWA Ref. No. | RE Description | |
| 13 | Front Axle Support | P10047 | 22 | Front Axle Pin 83 mm | |
| 14 | Steering Wheel | P10030 | 23 | M5 x 75 Screw | |
| 15 | Pedal | P10080 | 24 | M5 x 31 Screw | |
| 16 | Hitch Pin Assembly | P10017 | 25 | M5 x 12 Screw | |
| | M3 x 10 Screw | | 26 | M6 x 15 Bolt | |
| 17 | Pedal Crank Arm-s teel boo | dy P10335 | 27 | M5 x 38 Screw | |
| 18 | Bushing | P10032 | 28 | M4 x 6 Screw | |
| 19 | Hubcap | P10001 | 29 | ø4 x 20 T/Screw | > P10336 |
| 20 | Chain-Steel body | P10330 | 30 | ø 19 OD x ø11.8 ID Washer | / |
| 21 | Rear axle/sprocket | P10085 | 31 | ø24 OD x ø13 ID Washer | |
| | | | 32 | ø 14 OD x ø 4 ID Washer | |
| | | | 33 | Cotter Key | |
| This item carries a 1 year warranty. To purchase replacement parts please visit | | | 34 | Tooth Washer Nut M6 | |
| Toparenas | | hase replacement parts, please visit | 35 | Tooth Washer Nut M5 | |
| Col. Brook Bline's COEON LICA | | osite at www.tomy.com. | 36 | Square Nut M5 | |
| | | lacement parts within our 1 year warranty, please call 1-800-704-8697 | 37 | Capnut 11 mm | 1 |

Oak Brook, Illinois 60523, USA
All Rights Reserved. Made in China.
Please retain this instruction sheet for future reference.